



Installation Instructions

Speed Humps fixed into concrete surface



Please ensure you are wearing your correct safety gear before installing your speed humps



Tools and Equipment

- Hammer drill with a 10mm masonry bit
- 12mm dynabolts
- 12mm socket
- Industrial vacuum
- Hammer



Instructions

1. Select the right location of where the speed humps will be located.
2. Mark the ground to ensure you have a straight line
3. Hold the first speed hump segment in place and using a hammer drill with a 10mm masonry bit, drill 60mm deep holes through the designated point in the speed hump segment.
4. Hold the 12mm dynabolt, hammer into the ground and tighten with a 12mm socket.
5. Repeat for each hole and segment.

For best results we suggest the speed humps are placed on a flat surface.

For more information on the LSP Speed Hump range please visit the LSP website at

www.lpsafety.com.au